


Dr Brown's
natural flow®



Sippy Spouts and Sippy Bottles

Read and save these instructions for future use.

Dr. Brown's Milestones™ soft silicone sippy spout and sippy bottle are designed to help your child transition from bottle to cup. The sippy spout can also be used in place of the nipple/teat on Dr. Brown's® Options+™ Bottles when the internal vent system has been removed. **Sippy spout will not work properly with the vent system installed, or in non-Dr. Brown's® Options+™ Bottles.**

BEFORE FIRST USE

Use clean hands and clean surfaces when handling. Disassemble, clean the product and then place the components in boiling water for 5 minutes to ensure hygiene. Wash all parts prior to use. Be sure the spout hole is clean.

BEFORE EACH USE

Pull on the spout in all directions before each use to make sure it does not tear. Inspect carefully, especially when the child develops teeth, and replace the spout immediately if it shows any signs of wear or damage, such as cracking or change of shape. Small pieces can accidentally be inhaled and cause serious injury. Clean before each use. The spout must be clean and free of obstructions.

CLEANING

All parts are dishwasher safe (top rack only). Safe for use in electric sterilizer, microwave sterilizer or boiling water.

SIPPY BOTTLE ASSEMBLY

Insert sippy spout from bottom side of collar and pull spout from top until it snaps into place. Fill bottle for feeding and tighten collar with spout onto bottle. If your sippy bottle has Dr. Brown's Silicone Handles, place bottle on a firm surface, place handles over neck of bottle and push down into place on bottle. When removing handles from bottle, soapy water may help handles slide off more easily. When transporting bottles, always keep them upright with cap on to help prevent leaking.

For your child's safety and health

WARNING!

- Continuous and prolonged sucking of fluids will cause tooth decay.
- Always check food temperature before feeding.
- Throw away at the first signs of damage or weakness.
- Keep components not in use out of the reach of children.
- Never attach to cords, ribbons, laces or loose parts of clothing. The child may be strangled.
- Never use sippy spout as a pacifier/soother.
- Remove from your baby's mouth when the baby is not feeding.
- Always use this product with adult supervision.
- Always check the spout for signs of wear and replace when damaged.
- Do not use a microwave oven to heat the bottle as microwave ovens can create hotspots in milk/formula and/or bottle components.
- The bottle components are not toys and should not be given to children to play with or suck on.
- Do not leave the product in direct sunlight, heat or in disinfectant (sterilizing solution) for longer than recommended as this may weaken the spout.
- Change spouts after approximately six weeks of use.
- When used and sterilized intensively, spouts may deteriorate after six weeks.
- Do not allow a child to walk or run while using any bottle.