

For your child's safety and health WARNING!

Always use this product with adult supervision. Before each use, inspect the product. Throw away at the first sign of damage or weakness. Never leave baby alone while using the feeder. Keep all components not in use out of reach of children.

Cleaning

Wash all parts prior to use. Always use clean hands and surfaces.

- 1. Fully disassemble all parts.
- 2. Silicone bulb first use only: boil in water for five (5) minutes.
- 3. Wash all parts thoroughly in hot water and detergent.
- 4. Dishwasher safe (top rack only). Safe for use in electric sterilizer, microwave sterilizer or boiling water.

Before each use

Pull on the bulb in all directions before each use to make sure it does not tear. Inspect carefully, especially when the child develops teeth, and replace the bulb immediately if it shows signs of wear or damage, such as cracking or change of shape. Small pieces can accidentally be inhaled and cause serious injury. Do not leave bulb in direct sunlight, heat or leave in sterilizing solution for longer than recommended, as this may weaken the bulb. Clean before each use. The bulb must be clean and free of obstructions.

Loading the feeder

1. Place bulb into the collar and pull so that the rim of the bulb lays flat.

- 2. Load the bulb with the food of your choice.
- 3. Attach the handle by twisting collar until tight.



